

Fridge/Freezer care

Please defrost freezers carefully. To defrost empty the contents of your freezer, press the grey button on the temperature dial and leave it to defrost (place an empty basin on the top shelf and a towel on the floor outside of the fridge to catch the soakage)

Never scrape out the ice with a sharp object as it could burst the gas pipe, resulting in a new fridge/freezer being required at a cost to you the tenant.

Your fridge should always be set to the temperature of “3” for optimal fridge/freezer combination