

## **Electric Showers – Ensuite bathrooms**

The showers in Glasan have motors that are electrically powered so as soon as you push the start button you should instantly hear the motor running. There is a chord hanging from the ceiling which controls the power supply to the shower. If you press the start button and the motor does not start instantly, try pulling this chord as it may simply be that the main power supply has been turned off. Pull the chord gently until you hear a click. It is the same action to turn on this main power supply as it is to turn it off. This is the most frequent mistake that residents make so if the shower does not appear to be working, 9 times out of 10, this is the solution.

## **Emersion Showers – Main bathrooms**

Firstly, please note that the showers in Glasan are not instant heating showers. The hot water supply comes from a Hot Water Heating Tank, also known as an Immersion. The control panel for the Immersion is located outside the hot press cupboard at the top of the stairs in.

- Set Emersion timer to the current time, use summer and winter function
- Leave timed settings on at all times
- This should give you a hot tank of water between 4am and 8am
- Use boost when you require hot water outside of the above hours – this will heat half a tank

**Extractor Fan: IT IS ESSENTIAL** that the extractor fan is left on for at least 15 minutes after you have had a shower to remove the moisture from the air. If you turn off the fan as soon as you leave the bathroom the moisture will condense and you will end up with mould on your ceiling.