

INSTRUCTIONS FOR WATER HEATER



Water Heater Timer

The water heater panel is located either on the inside or outside wall of your hot press. Tenants will need to programme this to heat a full tank of water from the hours of 4am to 8am using the economy night-saver rate, thus reducing costs and saving the environment.

The timer is programmed by choosing the current time either in the summer or winters, depending on the season i.e. set it to 12pm under summer time if you have just checked in at midday, turn the switch to on and leave in this position going forward.

- The switch marked 'Water Heater Off / Timed' must always be switched to 'Timed' – this is on the top-right of the water heater panel
- The 24-hour clock must be set to the correct time – this is on the top-left of the water heater panel

Water Heater Booster

If you run out of hot water during the day you will need to boost it by turning the 'Boost' dial – this is under the timer clock on the bottom-left of the water heater panel. This is different from the timer heater for a number of reasons:

1. As the name suggests it boosts the amount of hot water you will have in a day – it will only heat half a tank of water at any one time.
2. As it is generally used by people in the evenings it uses daytime electricity which, **if used regularly, can be severe on the electricity bill for the house**
3. It has to be turned on every time it is required (whereas the timer is programmed to come on automatically)

The Boost can be turned on for a maximum of 2 hours at a time and turns itself off automatically. However if just one person requires hot water for a shower a half hour of boost heating should be more than sufficient. To do this, twist the pointer on the white dial anti-clockwise to the required time and it will heat the water while ticking back to the 'Stop' mark.